

**RX5**  
7.5"  
(241mm)      9.5"  
(190mm)



**RX7**  
13"  
(330mm)      10.5"  
(263mm)



**RX9**  
11"  
(279mm)      15"  
(381mm)



**RX12**  
13"  
(330mm)      20"  
(508mm)



**RX17**  
17"  
(432mm)      17"  
(432mm)



**RX20**  
22"  
(559mm)      20"  
(508mm)






				
Make	Model	Vertical Monitor	Horizontal Monitor	
<b>ADAM Audio</b>	A3X	RX5		
	A5 / A5X	RX5		
	A7 / A7X	RX7		
	A8X	RX7		
	ANF10	RX7	RX9	
	P11A	RX7	RX7	
	P22A	RX7	RX9	
	P33A		RX12	
	S1A / S1X	RX7		
	S2A / S2X	RX7		
	S2.5A	RX7		
	S3A / S3X-H		RX12	
	S3X-V	RX7		
	S4A / S4X-H	RX12*		
	S4X-V	RX17		
	SUB 8	RX7		
	SUB 10 MKII	RX17		
	SUB 12	RX17		
	SUB 20	RX7 x two		
	SUB 24	RX9 x two		
<b>Alesis</b>	M1 Active MKII	RX7	RX9	
	Monitor One MKII	RX7	RX9	
	M1 Active 520	RX5	RX7	
	M1 Active 620	RX7	RX9	


	M1 Active 320 USB	RX5	RX5
<b>ATC</b>	SCM16A	RX7	
	SCM100ASL	RX20	
	SCM25A		RX12
<b>Barefoot Sound</b>	MicroMain27	RX12*	RX12*
	MicroMain35	RX7	
<b>Behringer</b>	B1030	RX5	
	B1031	RX7	
	B2030	RX7	
	B2031	RX7	
	B2092	RX20*	
	B3030	RX5	
	B3031	RX7	
<b>Blue Sky</b>	EXO	RX5	RX5
	SAT 5	RX7	RX7
	SAT 6.5	RX7	RX9
	MEDIA DESK SAT	RX5	RX5
			
<b>Make</b>	<b>Model</b>	<b>Vertical Monitor</b>	<b>Horizontal Monitor</b>
<b>Digidesign</b>	RM1	RX7	RX7
	RM2	RX7	RX9
<b>Dynaudio</b>	BM5A	RX7	RX9
	BM6A	RX7	RX9
	BM15A	>RX7*	RX17
	AIR 6	RX7	RX9
	AIR 15	RX7	RX9

	AIR 20	RX17	
	SUB 250	RX7*	
	SUB 300	RX17	
	SUB 500	RX20	
	AIR BASE 1	RX20	
	AIR BASE 2	RX12	
	BM9S	RX7	
	BM10S	RX12	
	BM12S	RX20	
	BM14S	RX12	
<b>Event</b>	Event Opal	RX7	
	Studio Precision 6	RX7	RX9
	Studio Precision 8	RX7*	RX9
	TR6	RX7	RX9
	TR8	RX7	RX9
	S100	RX9	
<b>Equator</b>	Q8	RX7*	
	Q10	RX17	
	Q12	RX17	
	Q15	RX20	
<b>Focal</b>	CMS40	RX5	
	CMS50	RX5	
	CMS65	RX7	
	CMS Sub	RX17	
	SM11 L&R		RX12
	SM11C		RX12*
	SM8	RX7	RX9
	Solo6 Be	RX7	RX9
	Twin6 Be	RX7	RX12
	Sub6 Be	RX17	

			
Make	Model	Vertical Monitor	Horizontal Monitor
<b>Fostex</b>	PM0.5 MKII	RX5	RX7
	PM1 MKII	RX7	RX9
	PM2 MKII	RX7	RX9
	PM0.5 SUB	RX17	
<b>Genelec</b>	1029A	RX5	RX7
	1030A	RX5*	RX9*
	1031A	RX7	RX9
	1032A	RX9	RX12
	8020A	RX5	
	8030A	RX5	
	8040A	RX7	
	8050A	RX7	
	7050B	RX9	
	7060B	RX17	RX17
	7260A	RX12 x two	
<b>JBL</b>	LSR6325P-1	RX5	RX7
	LSR6328P	RX9*	RX9*
	LSR4326P	RX7	RX9
	LSR4312SP	RX17*	
	LSR6312SP	RX7 X two	
	LSR4328P	RX7	RX9
<b>Klein &amp; Hummel</b>	O 110	RX5	RX7*
	O 300	RX9	
	O 410	RX12	

				
Make	Model	Vertical Monitor	Horizontal Monitor	
<b>KRK</b>	RP5	RX5		
	RP6	RX7		
	RP8	RX7		
	VXT4	RX5		
	VXT6	RX7		
	VXT8	RX7*		
	E8B	RX17		
	V4	RX5	RX5*	
	V6	RX7	RX9	
	V8	RX7	RX9*	
	V12	RX20		
	RP10S	RX17		
<b>M-Audio</b>	EX66	RX5*	RX12	
	BX5a	RX5	RX7	
	BX8a	RX7*	RX9*	
	DX4	RX5	RX5*	
<b>Mackie</b>	MR5	RX7		
	MR8	RX7		
	HR624	RX7	RX9	
	HR626		RX12	
	HR824	RX7	RX9	
<b>Manley</b>	ML10	RX9	RX12	
<b>Meyer Sound</b>	HD 1	RX17	RX17	

<b>M&amp;K Professional</b>	240IP	RX7	
	1501P	RX5	
	1601P	RX5	
	1611P	RX7	
	2510P	RX7*	
<b>PMC</b>	AML1	RX7	
	LB1	RX7	
	DB1S-A	RX5*	RX7*
	TB2S-A	RX7*	RX9*



<b>Make</b>	<b>Model</b>	<b>Vertical Monitor</b>	<b>Horizontal Monitor</b>
<b>ProAC</b>	Studio 100	RX7	RX9
	Studio 110	RX7	RX9
	Studio Center Channel		RX9*
	ER1 Sub	RX17	
<b>PSI</b>	14M	RX5	RX5*
	17M	RX5	RX7*
	21M	RX7	RX9*
	25M	RX17	RX12*
	225M	RX17*	RX20*
<b>Quested</b>	S6R	RX5	
	S7R	RX7	
	S8R	RX7	
	VS2108	RX7*	
	V3110	RX12	RX17

	H108	RX7	
	VH3208	RX17	
<b>SLS</b>	S8R	RX7*	RX12
<b>Samson</b>	Resolv A5	RX5	RX7
	Resolv A6	RX7	RX9
	Resolv A8	RX7	RX9*
<b>Tannoy</b>	Reveal 5	RX5*	RX9
	Reveal 6D	RX7	RX9
	Reveal 66	RX12*	
	Reveal 8D	RX7*	RX17
	Precision 6	RX7	RX9
	Precision 8	RX7*	RX12
	System 600	RX7	RX9
	System 800	RX7*	RX12
	TS8	RX7*	
	TS10	RX7*	
	TS12	RX17	
	TS112 IDP	RX17	
<b>Westlake</b>	LC 4.75	RX5	
	LC 5.75	RX5	RX9
	LC 6.75	RX7	
	LC 3w10	RX12*	RX12
	LC 3w12		RX20*
	LC 265.1	RX12*	
	LC 24.75	RX9*	
	LC 8.1	RX7	
	BBSM-4	RX9	
	BBSM-5	RX12	
	BBSM-6	RX12*	



<b>Yamaha</b>	MSP3	RX5	RX5
	MSP7	RX7	RX9
	MSP10	RX7	RX9
	HS 50M	RX5	RX7
	HS 80M	RX7	RX9
	NS-10	RX7	RX9
<b>Yorkville</b>	YSM1-P	RX7	RX9
	YSM2-P	RX5*	RX7